

Snom 360 Soft Phone Settings

snom SoftPhone - InstallShield Wizard
X

snom

VoIP-phones

Initial Settings
Please enter the initial setup information.

Your Name (e.g. Fred Feuerstein):

Account Number (e.g. 979443543):

SIP Registrar (e.g. company.com):

Password:

snom 360
+

localhost:61099/line_login.htm?l=1

Configuration Line 1

Operation

- Home
- Address Book

Setup

- Preferences
- Speed Dial
- Function Keys
- Line 1
- Line 2
- Line 3
- Line 4
- Line 5
- Line 6
- Line 7
- Line 8
- Line 9
- Line 10
- Line 11
- Line 12
- Action URL Settings
- Advanced
- Trusted Certificates

Status

- System Information

Login
SIP
NAT
RTP

Login Information:

Line active: on off

Displayname:

Account:

Password:

Registrar:

Outbound Proxy:

Authentication Username:

Mailbox:

Ringtone:

Custom Melody URL:

Display text for idle screen (max. 10 chars):

XML Idle Screen URL:

Record Missed Calls: on off

Save
Re-Register
Logoff
Logoff All
Play Ringer